

Table 491**CRYSTAL UNIT, QUARTZ: TYPE AY**

Illustration No. 8

Use: TBS Receiver**Spec:** LC-136**NATOSC:** 35084

| NATO Stock No. | Channel Freq Mc | Crystal Freq Mc |
|-----------------------|----------------------------|----------------------------|
| ●5955-21-460-0004 | 65.34 | 15.0100 |
| ●5955-21-460-0005 | 65.74 | 15.1100 |
| ●5955-21-460-0006 | 72.10 | 16.7000 |
| ●5955-21-460-0007 | 72.50 | 16.8000 |
| ●5955-21-460-1699 | 72.90 | 16.9000 |

Table 493**CRYSTAL UNIT, QUARTZ: TYPE AX**

Illustration No. 8

Use: TBS Transmitter**Spec:** LC-136**NATOSC:** 35084

| NATO Stock No. | Channel Freq Mc | Crystal Freq Mc |
|-----------------------|----------------------------|----------------------------|
| ●5955-21-460-0000 | 65.34 | 16.3350 |
| ●5955-21-460-0001 | 65.75 | 16.4350 |
| ●5955-21-460-0002 | 72.10 | 18.0250 |
| ●5955-21-460-0003 | 72.50 | 18.1250 |
| ●5955-21-460-1698 | 72.90 | 18.2250 |