




C_{dG} - LOAD TORQUE DISTURBANCE

θ_d - BASE MOTION

θ_G - GUN POSITION

$\Delta\theta_G$ - STABILIZATION ERROR

J_m - MOTOR INERTIA MOMENT

θ_{DEMAND} - FCS DEMAND ANGLE