




STATUS PANEL



REMOTE LAUNCH
ENABLE PANEL



29 CELL VERTICAL LAUNCHER



LAUNCH CONTROL UNIT

VERTICAL LAUNCH SYSTEM

Figure 14 Vertical Launch System